

mSORB® 5A
MOLECULAR SIEVE BEADS, TYPE 5ACHEMICAL FORMULA
 $CA_{4,5} [(AL_0.2)_{12}(SiO_2)_{12}] \cdot NH_2O$ **PRODUCT DESCRIPTION**

mSORB 5A molecular sieve is an alkali metal aluminosilicate in the spherical form. It is the calcium form of the type A crystal structure with an effective pore opening of 5Å. Molecules with effective diameters greater than 5Å, such as, iso-compounds and all 4-carbon rings will not be adsorbed. Adsorbed molecules include NC_4H_{10} , nC_4H_{10} , C_3H_8 to $C_{22}H_{46}$, and Freon 12 (dichlorodifluoro-methane).

TYPICAL PROPERTIES		
PRODUCT CODE	5A812B	5A48B
Nominal Pore Opening (Å)	5	5
Shape	Bead	Bead
Particle Size (Mesh)	8 X 12	4 X 8
Equilibrium Water Capacity @ 25°C (wt%)	≥ 21	≥ 21
Heat of Adsorption (BTU/lb of H ₂ O)	1800	1800
Bulk Density (g/ml)	≥ .7	≥ .6
Bulk Density (lb/ft ³)	≥ 42	≥ 41
Crush Strength (lb)	≥ 7	≥ 24
Crush Strength (N)	≥ 30	≥ 110
Size Qualification (%)	≥ 96	≥ 96
Package Moisture (wt%)	≤ 1.5	≤ 1.5

TYPICAL APPLICATIONS

Using selective adsorption to remove normal and iso-paraffins from branched chain and cyclic hydrocarbons, natural gas drying, removal of H₂S, CO₂ and mercaptans from natural gas, inert gas purification, H₂ purification, PSA oxygen purification, solvent drying, and separation of aromatics.

PACKAGING INFORMATION

Available in 55 lb (25 kg) drums, 330 lb (150 kg) drums, and super-sacks filled to order specification.

HANDLING & STORAGE RECOMMENDATIONS

Store in a dry location to prevent unintentional water adsorption. Reseal packages after opening to prevent contamination and unintended water adsorption. We recommend that you rotate stock so oldest material is used first.

IGC001115